



HIGH VOLTAGE DRIVERS

2DPB3-4000-1.7-AI

2DPB3-6000-1.3-AI

Technical Description
Rev. 2206

2022
Lithuania

CONTENTS

CHAPTER 1	WARRANTY	1
1.1.	WARRANTY STATEMENT	1
1.2.	SERVICE CONTACT INFORMATION	1
CHAPTER 2	SPECIFICATIONS	2
2.1.	GENERAL INFORMATION	2
2.1.1.	<i>Models</i>	2
2.1.2.	<i>Main Components</i>	2
2.2.	TECHNICAL SPECIFICATIONS	3
CHAPTER 3	DEVICE LAYOUT	4
CHAPTER 4	SAFETY	6
CHAPTER 5	IMPORTANT NOTES	7
CHAPTER 6	QUICK START GUIDE	8
6.1.	CONNECT WIRES TO THE POCKELS CELL	8
6.2.	GROUND THE POCKELS CELL DRIVER TOGETHER WITH THE GENERATOR AND HV SUPPLY	8
6.3.	SUPPLY VOLTAGE TO THE DRIVER FROM THE DC POWER SUPPLY	8
6.4.	SUPPLY VOLTAGE FROM THE HV SUPPLY	8
6.5.	PROVIDE SYNCHRONIZATION PULSES FROM THE GENERATOR	8
6.6.	OPERATION	9

LIST OF FIGURES

FIGURE 1. OUTLINE DRAWING AND DIMENSIONS OF THE DRIVER.....	4
FIGURE 2. VIEW OF THE DRIVER	5
FIGURE 3. DRIVER OPERATION CHART	7
FIGURE 4. INPUT CIRCUIT OF DRIVER.....	9
FIGURE 5. CONTROL 2DPB3 DRIVERS WITH FREQUENCY DOUBLING	9
FIGURE 6. CONTROL 2DPB3 DRIVERS WITH FREQUENCY DOUBLING AND POLARITY ALTERNATING	10
FIGURE 7. CONTROL 2DPB3 DRIVERS BY TUNING OUTPUT PULSE DURATION	10

LIST OF TABLES

TABLE 1. MODELS	2
TABLE 2. MAIN COMPONENTS	2
TABLE 3. TECHNICAL SPECIFICATIONS.....	3
TABLE 4. PORTS SEEN ON VIEW OF THE DRIVER	5

1.1. Warranty Statement

The Pockels cell drivers are protected by a one-year warranty covering labor and parts. The warranty enters into validity since the shipment date. Any evidence of improper use or unauthorized repair attempts voids the warranty.

1.2. Service Contact Information

For service/warranty requests, please contact:

EKSMA OPTICS, UAB
c/o EKSMA Optics, UAB
Dvarcioniu st. 2B
LT-10233 Vilnius, Lithuania

Phone: +370 5 272 99 00
Fax.: +370 5 272 92 99
E-mail: info@eksmaoptics.com
Website: www.eksmaoptics.com

2.1. General Information

2.1.1. Models**Table 1. Models**

Model	Description
2DPB3-4000-1.7-AI	2 x 2000kHz repetition rate, 1.7kV positive polarity output
2DPB3-6000-1.3-AI	2 x 3000kHz repetition rate, 1.3kV positive polarity output

2.1.2. Main Components**Table 2. Main components**

Component	Quantity	Notes
High voltage (HV) driver 2DPB3-*-**	1	-
DC power cable (l=1.5m)	1	-
BNC-SMB cables (l=1.5m)	2	-
HV power supply cable (l=1m)	1	-
Wires for HV output to the Pockels cell (<10 cm)	2	-
Technical description	1	-

2.2. Technical Specifications

Table 3. Technical specifications

<i>Parameter</i>	<i>Value(s)</i>	
	<i>2DPB3-4000-1.7-AI</i>	<i>2DPB3-6000-1.3-AI</i>
Maximum working (HV supply) voltage, <i>kV</i>	+1.9	+1.5
Maximum output voltage (HV), <i>kV</i>	1.7	1.3
Polarity of output pulses	Positive	
Maximum HV consumption (6 pF load), <i>W</i>	<360	<350
Maximum capacity load at maximum repetition rate and HV supply, <i>pF</i> ¹	6	
HV pulse rise/fall time, <i>ns</i> (6 pF load)	<10.5	<9
Output HV pulse duration with frequency doubling at maximal repetition rate, <i>ns</i>	0...100	0...66
Output HV pulse duration without frequency doubling at maximal repetition rate, <i>ns</i>	0...200	0...133
Minimum pause between output pulses, <i>ns</i>	100	
Maximum repetition rate using frequency doubling, <i>kHz</i>	4000	6000
Maximum repetition rate appearing on each of HV outputs, <i>kHz</i>	2000	3000
HV pulse delay, typical, <i>ns</i>	30	
External triggering inputs	2	
External triggering pulse amplitude @50Ω load, <i>V</i>	3.5...5	
External triggering pulse rise time, <i>ns</i>	<5	
External triggering pulse duration at maximal repetition rate, <i>ns</i>	100...300	100...233
Maximal triggering frequency, <i>MHz</i>	2	3
Low voltage DC requirements	+24V ±1V	
	0.75A	1.05A
DC Connector	Molex Micro-Fit 3.0	
Maximal operating temperature of base plate, °C	35	
Water connector	"Festo" for OD=6mm tube	
Dimensions, <i>mm</i>	220x87x98	
Weight, <i>g</i>	3100	

¹ Voltage or repetition rate derating is necessary if capacitance of your Pockels cell is higher. Contact manufacturer for details.




Figure 1. Outline drawing and dimensions of the driver




Figure 2. View of the driver

Table 4. Ports seen on view of the driver

#	Port
1.1	X1(SYNC IN1)
1.2	X2 (SYNC IN2)
2	Jumper should be in position 1_2
3	Connector Molex 4 (Microfit series) - interface for +DC (24 VDC) supply ("A" is +DC; "B" is GND)
4	HV pulse output connector ¹
4.1	OUT1 to Pockels cell
4.2	OUT2 to Pockels cell
5.1	+HV input from HV supply
5.2	GND input from HV supply
6.1	GND input from HV supply
6.2	+HV input from HV supply
7	Water cooling connectors

¹ Can be mounted on opposite side by request.

Equipment is designed to be safe under normal environmental conditions according to 1.4.1.61010-1@IEC:2010 (Safety requirements for electrical equipment, control and laboratory use):

1. indoor use;
2. altitude up to 2000 m;
3. temperature 5°C to 35°C;
4. maximum relative humidity 80% for temperatures up to 31°C decreasing linearly to 50% relative humidity at 35°C;
5. POLLUTION degree 1: no POLLUTION or only dry, non-conductive POLLUTION occurs.

Warning:

The safety of the system incorporating driver and HV power supply is the responsibility of the assembler of the system.

Operating the driver is allowed to persons acquainted with the operation manual and having permission to deal with voltages over 1000 V.

Do not remove unit covers while power cable is connected to the mains (if applicable).

Do not touch any parts of the system when high voltage is applied, as it may cause injury or death.

Do not operate the unit until it is **grounded** and the load is connected.

Do not use the unit if any defects have been detected.

Please read these important notes before using the product!

1. External triggering pulses to inputs **X1** (SYNC IN1) and **X2** (SYNC IN2) may be applied only if high voltage and DC power are provided and turned on. When turning off the driver, first turn off synchronization pulses, then turn off the power. Otherwise the driver can be damaged.




Figure 3. Driver operation chart

2. The output pulse is provided between **OUT1** and **OUT2**. Both outputs are hot. Do not connect an oscilloscope or any other device to the OUT pins. The wire contact with the Pockels cell must be proper in order to avoid a discharge, which may damage the driver. Do not power the driver without a capacitive load (4...10 pF) as this may damage the driver.

3. The pulse shape (including fronts) can be measured indirectly. On your oscilloscope, select 1 V sensitivity and the 1 MΩ input. Use isolated 1:10 oscilloscope probe for measurement. Move the probe *slowly* and *carefully* toward the hot output wire. When the probe is ~10 mm away from the hot output wire, the pulse shape should appear in the oscilloscope (amplitude should be several volts). Do not place the probe too close to the hot output wire – a discharge may start and damage the driver. This measurement method is not suitable for measuring >500 ns pulses.

4. Do not attempt to measure the parameters of any part of the driver's electronics using an oscilloscope, especially when the driver is running in pulsed mode. Attempts to measure parameters of certain parts of the driver's circuitry may lead to damage.

6.1. Connect wires to the Pockels cell

The wires leading from outputs **OUT1** and **OUT2** to the Pockels cell must be about 0.24 mm² CSA. Both the wires must be as short as possible and equal length. The length of each wire must be not exceeding 100 mm. They should be located at least 5 mm away from any conductive material (including the operator's fingers and instruments) – this is done to avoid any additional capacitive load. Otherwise, driver characteristics may degrade and/or the driver may get damaged.

6.2. Ground the Pockels cell driver together with the generator and HV supply

The driver output of several kilovolts (kV) with very fast edges is a powerful source of electromagnetic interference (EMI). Please ensure proper wiring and grounding to avoid problems caused by interference.

The best solution to minimize EMI is mounting the driver and the HV power supply on the metal body of the laser. Use mounting holes of the driver and HV supply to ground them together with laser body. Ensure that these connections are firmly tighten and has god electrical connection. This is enough in most of cases.

If the EMI level is still very high, attempt mounting ferrites on all power and control wires leading to the driver and power supply (except wires to the Pockels cell).

Please note that the aluminum case of the driver is not designed to provide effective EMI shielding. Essentially, correct wiring gives the best result.

6.3. Supply voltage to the driver from the DC power supply

For a safe start of the driver, the DC power supply must provide at least 0.6 A peak current when turning on. Although most DC power supplies are capable of providing this, it is recommended to double-check your supply as an insufficient peak current may damage the driver.

6.4. Supply voltage from the HV supply

Connect the HV power supply and set required voltage.

If the HV power supply is manufactured by a third party, before supplying voltage, ensure there is no overvoltage while turning it on.

6.5. Provide synchronization pulses from the generator

It is necessary to measure the generator output voltage with a 50Ω load before applying synchronization signals to the driver. The amplitude must be in range 3.5...5 V. Make sure that the duration of SYNC IN pulses is longer than 100 ns.

After the generator output voltage is measured, remove the 50Ω load and provide synchronization pulses to the driver.

Figure 4 presents the input circuit.




Figure 4. Input circuit of driver

6.6. Operation

1. Operation with frequency doubling. Output pulses to Pockels cell appear double frequency as any of trigger input. Figure 5 presents the principle. SYNC1 and SYNC2 are triggering inputs. Corresponding outputs OUT1 and OUT2 of the driver repeats the time scale of SYNC inputs and presents amplitude in kV. Resulting HV pulse on Pockels cell appears as difference of these two outputs. Pulse duration to Pockels cell is tuned by shifting SYNC input's edges toward directions marked by arrows t simultaneously. The width of pulse SYNC1 must to be about 0.5 period or longer. The pulse duration can be tuned down to 0 unlike as in regular Pockels cell drivers.




Figure 5. Control 2DPB3 drivers with frequency doubling

2. Operation with frequency doubling and alternating voltage polarity on Pockels cell. SYNC2 pulses train is like SYNC2 but delayed in time. Output pulse duration is equal to time shift in between these two SYNC pulse trains. The pulse duration can be tuned down to 0 unlike as in regular Pockels cell drivers. Note that voltage amplitude on Pockels cell can be lower than HV supply by 20%...30% depending on Pockels cell capacitance.




Figure 6. Control **2DPB3** drivers with frequency doubling and polarity alternating

3. Operation with no frequency doubling and pulse duration tuning possibility from maximal down to zero. Pulse duration to Pockels cell is tuned by shifting SYNC input's edges toward directions marked by arrows.




Figure 7. Control **2DPB3** drivers by tuning output pulse duration